



VFM60 Series Vortex Flowmeter

Introduction Manual

CONTENTS

1 General	
1 General	4
1.1 Model Number and General Specification	4
1.2 Packing List	4
1.3 Storage	4
1.4 Hazardous Area Installation	5
1.5 Measuring principle	5
2 Installation	6
2.1 Find Most Suitable Location	6
2.2 Requirement on straight pipe line	6
2.3 Wafer type	10
2.4 Flange type	12
3 Wiring	15
3.1 Shell grounding and elimination of interference	15
3.2 Requirements for wiring	16
3.3 Wiring for 5-terminal board (power supply+RS485)	16
3.3.1 Wiring for 3 wire pulse output	16
3.3.2 Wiring for 2 wire HART@4~20mA	17
3.3.3 Wiring for RS485	17
3.4 Wiring for 12-terminal board(power+4~20mA+RS485)	17
3.4.1 Wiring for 3 wire pulse output	17
3.4.2 Wiring for 4 wire 4~20mA	18
3.4.3 Wiring for 4 wire HART@4~20mA	18
3.4.4 Wiring for RS485	19
3.5 Wiring for remote type	20
4 Display	20
4.1 Instruction of multi-functional LCD display	20
4.2 Unit of the variable displayed	22
4.3 Three button setting	22
4.4 Total flow displaying	23
4.5 Status	24
5 Setting	24
5.1 Code setting	24
5.2 Digital setting	25
5.3 Setting list	26
5.4 Example of setting	31
6 Password	31
6.1 Turn on the password function	31
6.2 Change the password	32
7 Instruction of RS485 Modbus Communication	32
7.1 Interface regulation	32

7.2 Commends	35
7.3 Calculation of CRC parity code	35
7.4 The float data format of the instrument.....	35
7.5 The sequence of the float data bytes of instrument	36
7.6 Modbus error response.....	36
7.7 Examples of communication.....	37
8 Introduction of HART communication protocol	38
8.1 HART commands.....	38
8.1.1 Command 0: Read transmitter unique identifier	38
8.1.2 Command 1: Read primary variable value (PV).....	39
8.1.3 Command 2:Read primary variable's current and percentage value.....	39
8.1.4 Command 3:Read primary variable current and dynamic variables	40
8.1.5 Command 6:Write polling address.....	40
8.1.6 Command 11:Read unique identifier associated with tag	41
8.1.7 Command 12:Read message	41
8.1.8 Command 13:Read tag, descriptor, date	42
8.1.9 Command 14: Read primary variable sensor information: device serial number and limits	42
8.1.10 Command 15: Read primary variable output information	43
8.1.11 Command 16: Read final assembly number.....	43
8.1.12 Command 17: Write message.....	43
8.1.13 Command 18: Write tag, descriptor, date.....	44
8.1.14 Command 19: Write final assembly number.....	44
8.1.15 Command 34: Write primary variable damping value	44
8.1.16 Command 35: Write primary variable range values.....	45
8.1.17 Command 36: Write primary variable upper limit value	45
8.1.18 Command 37: Write primary variable lower limit value	46
8.1.19 Command 40: Enter/Exit primary variable current mode.....	46
8.1.20 Command 45: Trim primary variable current DAC zero	47
8.1.21 Command 46: Trim primary variable current DAC gain	47
8.1.22 Command 140: Reset totalizer	47
9 Maintaining	48
9.1 How to changing the housing orientation	48
9.2 Replace the transmitter circuit board	48
10 Troubleshooting and repair	49
10.1 Safety introduction.....	49
10.2 Diagnostic information.....	49
11 Remark	52
Appendix.....	52

1 General

Every VFM60 vortex flowmeter will be carefully inspected before delivered to users.

Please carefully check if there is any damage on the package and product when you received them

Please check if the package contains all the accessories according to 1.2 or your purchase order.

Please make sure the person in charge of this device has carefully read this manual and understand its descriptions.

1.1 Model Number and General Specification

Please check if the model number and specifications on the name plate match your requirement on the purchase order.

Please kindly record the model number and instrument ID code, which will be required if you need and service or support from us.

1.2 Packing List

When you received the package, please check if it contains the items as below:

VFM60 vortex flowmeter x1

User's manual x1

Calibration certificate x1

Quality certificate x1

Cable (For remote type only, length according to customer's requirement)

Counter flanges (For wafer type, or for flange type when customer required so)

Screws and bolt (For wafer type, or for flange type when customer required so)

1.3 Storage

If the product needs to be stored for a long period before use, please be aware of below:

- (1) The product should be kept in the origin package and same as it was when received.
- (2) Please store the product in a proper location according to the requirements below:

Not in a uncovered field.

Not in a location where could have great vibration.

Please keep the enclosure of the meter closed.

The ambient temperature, atmospheric pressure and humidity should be:

Temperature: -20~+60°C ; RH: 5%~99% ; Pressure: 86~106Kpa

1.4 Hazardous Area Installation

Our vortex flowmeter can be installed in hazardous area according to the approval below:

Ex d IICT3 (NEPSI)

1.5 Measuring principle

Vortex flowmeter measures the flow by sensing the vortices in the flow according to “Karman Vortex Street”. When put a shedder in the path of flow, vortices are alternately shed on each side (see picture 1.2)



Picture 1.1 Von Karman vortices

The frequency of vortices (f) is in direct ratio with velocity of flow (v) and in inverse ratio with width of obstacle (d).

$$f = St \cdot v / d \text{ (formula 1)}$$

$$v = fd / St \text{ (formula 2)}$$

St is Strouhal Number, is a dimensionless constant related to shape of the shedder, which can be get by testing. St is Strouhal Number, is a dimensionless constant related to shape of the shedder, which can be get by test.

Because d and St is constant, flow velocity (v) and average velocity (v0) also have certain relationship ($v_0 = v / (1 - 1.25d/D)$), so, you could get v0 by having the frequency of vortices shedding (f), and then get the mass flow. The ration between quantity of vortex in a certain period and the volume of the flow pass by is called coefficient of the instrument (K)

$$K = N / V \text{ (formula 3)}$$

VFM60 series digital vortex flowmeter is designed to provide most reliable performance. This series of vortex flowmeter is designed on PA60 platform. Every part utilized is universal for all VFM60 series products. The circuit boards use signal isolation and self-diagnose technology. VFM60 series utilize spectrum analyzing signal process technology, which ensured lower under measuring limit and better turn down ratio. The enhanced version uses unique dual-sensor design and vibration signal analyzing technology to improve its anti-vibration capability and provide with more stable reading. VFM60 also has density calculation function as option, which means it can calculate the density and measure mass

flow rate of air/saturated steam/superheated steam without secondary device. It also has AGA-NX-19 and AGA-8 algorithm to measure natural gas directly.

2 Installation

2.1 Find Most Suitable Location

(1) Ambient temperature

Please avoid installing the flowmeter at a location where temperature could dramatically changes. If the meter is under heavy heat radiation, please implement effective heat insulation and venting method.

(2) Atmosphere

Please do not install the meter at a location where the atmosphere contains a high level of corrosive substance. If can not install the meter at a better location, please make sure there is enough venting.



(3) Vibration





The meter should not be installed at a location where could have strong vibration. If the mounting pipeline could have heavy vibration, the pipe line should be hold steady by some support racks.

(4) Caution





- (a) All screws and bolts should be tightened.
- (b) Make sure there is not leakage point on the connection.
- (c) The process pressure should not be higher than the meter's rated pressure.
- (d) Once the meter is under pressure, please do not screw the bolts and screws.



2.2 Requirement on straight pipe line

Standard	
Down sized	

Upsized	
Curve pipeline	
Dual-curve pipeline	
Steam measurement (Only allow installation in shadow areas)	 when medium over 150°C(302°F), recommend flow meter installs vertical to the pipeline (as picture), or install on a horizontal pipe, flow meter recommend to install in the shadow areas.

High temperature vortex flowmeter insulation instructions	When temperature over 160°C/320°F, pls add a thermal insulation layer to the pipeline according to the thermal insulation guidelines to prevent the temperature of the sensor and circuit part from exceeding +80°C/+176°F. The insulation layer should not cover the support rods. The insulation layer ④ can only extend up to the positions marked ①, ②, and ③ in the figure below. ① is the maximum position of the insulation layer ④ on the support rod, which must not be exceeded. ② is the maximum position of the insulation layer ④ of the temperature bend locking nut, which must not be exceeded. ③ is the maximum position of the insulation layer ④ at the bend of the pressure bend, which must not be exceeded. ④ is the insulation layer.
Valve in downstream	
Valve in upstream	

Pressure sensor: 2~7D downstream of flowmeter Temperature sensor: 1~2D downstream of pressure sensor	
Roots blower or piston blower or air compressor in upstream	 Roots blower or piston blower or air compressor or pump in upstream, could cause vibration of the fluid itself. To eliminate this vibration, please install a orifice plate or a up-sized pipe at about 25D upstream the meter. The valve should be located downstream the flowmeter in this condition
After a piston pump	 Please install a accumulator to reduce the vibration
T type pipeline in upstream	 When upstream pipe line is T type the flowmeter and a valve downstream the meter is shut (see above picture), the fluid will all flow towards direct B, but the meter may still have reading for it may be detecting the pulsating pressure. Please move the valve to upstream of the meter to avoid this situation

Gaskets should not get into the pipeline	
Pipe cleaning: If the pipeline needs to be cleaned, please use a substituted pipe to replace the flowmeter to avoid the meter being damaged by the cleaning fluid	

Please read the instructions carefully before installation: 2.1 Find Most Suitable Location

2.3 Wafer type

The following is for fixed pipe type. For movable pipe type, ignore steps 1 and 2


Step 1: Calculate the cut pipe width $S=A+2B+2C$

A: Width of wafer type vortex flowmeter body


B: Thickness of metal spiral wound gasket

C: Thickness of matching flange slot


(Use caliper to measure above, or see Table 1 on page 14 for S size)




Step 2: Cut the width S calculated in step 1 at the pipe installation location




Step 3: Place two metal spiral wound gaskets in the flange slots, clamp the vortex flowmeter as shown in the figure, and fix the flowmeter with matching bolts. Spot weld the matching flange at the cut to make sure the flange is firm




Step 4: Remove the vortex flowmeter and metal spiral wound gasket, and fully weld the two flanges.



Step 5: After the welding part cools down, place a matching metal spiral wound gasket on each side of the flange.



Step 6: Clamp the flowmeter (note that the flow indication direction of the flowmeter is the same as the direction of the pipeline fluid) and fix the flowmeter with matching bolts.



2.4 Flange type

The following is for the fixed pipeline type. For the movable pipeline type, ignore steps 1 and 2


Step 1: Calculate the width of the cut pipeline $S=A+2B+2C=L+2C$

A: The width of the flange type vortex flowmeter body (including the flanges on both sides)


B: The thickness of the metal spiral wound gasket

C: The thickness of the flange slot welded on the pipeline

(The above is measured with a caliper, or the L size is shown in table 2 on page 14)



Step 2: Cut a notch of width S on the pipe




Step 3: Place two metal spiral wound gaskets in the flange slots, clamp the vortex flowmeter as shown in the figure, and fix the flowmeter with fastening bolts. Spot weld the matching flange at the cut to make sure the flange is firm.




Be sure to remove the flow meter after spot welding to prevent high temperature from damaging the probe.


Step 4: Remove the vortex flowmeter and metal spiral wound gasket, and fully weld the two flanges.



Step 5: After the weld has cooled, place a metal spiral wound gasket on each side of the flange.



Step 6: Clamp the flowmeter (note that the flow indication direction of the flowmeter is the same as the direction of the pipeline fluid) and fix the flowmeter with fastening bolts.






Chart 1 (1.6~4.0Mpa)




Chart 2 (1.6~6.3Mpa)

Wafer type
1.6~4.0MPa

Size	$S = A + 2B + 2C$
15	79
20	79
25	79
32	79
40	79
50	81
65	85
80	83
100	108
125	87
150	86
200	97
250	128
300	134

Flange type 1.6~6.3MPa


Size	$L = A + 2B$							
	PN16	PN25	PN40	PN63	CLASS150	CLASS300	JIS10K	JIS20K
15	170	170	170	189	190	200	156	162
20	174	174	174	195	200	210	158	166
25	174	174	174	215	206	218	166	170
32	178	178	178	219	210	226	170	176
40	184	184	184	223	218	232	170	176
50	184	190	190	223	222	234	174	178
65	184	198	198	235	234	248	182	190
80	204	220	220	249	244	264	194	206
100	218	244	244	270	268	286	204	230
125	249	275	275	315	317	337	233	267
150	264	304	304	344	332	352	260	300
200	278	314	330	374	358	378	270	308
250	314	350	384	424	378	410	304	348
300	350	378	424	474	424	456	330	382

Note:


1. The following takes the multi-variable vortex flowmeter as an example. The width of the normal vortex flowmeter is the same as that of the multi-variable vortex flowmeter
2. The following A is the width of the vortex flowmeter body, B is the thickness of the metal spiral wound gasket, and C is the thickness of the matching flange slot.
3. The following flange type vortex flowmeter does not include the flange size C welded on the pipe.

3 Wiring


VFM60 vortex flowmeter has 3 different terminal boards, the five-core terminal board (power supply + RS485) as shown in Figure 3.1, the twelve-core terminal board (power supply + 4~20mA + RS485) as shown in Figure 3.2, the remote connection terminal board (for remote type) as shown in Figure 3.3.



Picture 3.1 five-core terminal board
(power supply + RS485)



Picture 3.2 twelve-core terminal board
(power supply + 4~20mA + RS485)



Picture 3.3 remote connection terminal board
(for remote type)

On above boards, V+ and V- are for power.  is pulse output terminal. A, B are “+” and “-” for RS485Modbus communication, I+ and I- are + and – for 3-wire or 4-wire 4~20 mA. RT1, RT2, RT3 are for separate RTD. P+, P- are for pressure transmitter. VFM60 multi –variable version has built in RTD and pressure sensor, so clients are not required to wire for temperature or pressure compensation. VIB+ and VIB- are upper probe signal line. VTX+ and VTX- are lower probe signal line.


3.1 Shell grounding and elimination of interference

In VFM60 digital vortex flowmeter the power supply of signal processing circuit is transferred from outside power supply by an isolation type DC-DC transmitter with advanced grounding technology. The field frequency interference can be isolated well.

When using this product, the “V-” of power supplier should not be connected with the ground. When this product is used in an environment with strong interference, the shell should be connected with earth through cable, so the interference can be eliminated.

3.2 Requirements for wiring

- 1) Don't conduct wiring when on an explosive environment.
- 2) Please open the rear cover first, then insert the cable into back zone of housing through the water-proof cable gland.
- 3) Conduct wiring according to 3.3 , 3.4 and 3.5.
- 4) If possible, please conduct the wiring according to picture 3.4 to avoid the water get into the housing through the cable.




Picture 3.4 wiring

3.3 Wiring for 5-terminal board (power supply+RS485)

3.3.1 Wiring for 3 wire pulse output


3-wire pulse output require a power source of 13.5~42VDC. VFM use a current pulse output with 50% duty ratio. If the pulse receive instrument require voltage pulse, the pull-up resistor between the pulse and the power supply is 1.5K and power consumption should be no less than 3W. Please reference to picture 3.3.1 picture below for 3-wire pulse output wiring



Picture 3.3.1: 3-wire pulse output wiring


3.3.2 Wiring for 2 wire HART@4~20mA

When there is not temperate and pressure compensation and the power source is 24VDC, the max load for 4~20mA analog is 500ohms. And when there is temperate and pressure compensation and the power source is 24VDC, the max load for 4~20mA analog is 400ohms. When using a HART communicator, please add a 250ohms load resistor



Picture 3.3.2 Wiring for 2 wire HART@4~20mA

3.3.3 Wiring for RS485




Picture 3.3.3 Wiring for RS485

3.4 Wiring for 12-terminal board(power+4~20mA+RS485)

3.4.1 Wiring for 3 wire pulse output


3-wire pulse output require a power source of 13.5~42VDC. VFM use a current pulse output with

50% duty ratio. If the pulse receive instrument require voltage pulse, the pull-up resistor between the pulse and the power supply is 1.5K, and power consumption should be no less than 3W.



Picture 3.4.1: 3-wire pulse output wiring


3.4.2 Wiring for 4 wire 4~20mA



Picture 3.4.2: Wiring for 4-wire 4~20mA


3.4.3 Wiring for 4 wire HART@4~20mA

When power source is 24VDC, the max load for 4~20mA analog is 500ohms.



Picture 3.4.3: Wiring for 4-wire HART@4~20mA


3.4.4 Wiring for RS485



Picture 3.4.4: Wiring for RS485

3.5 Wiring for remote type

Connect VIB+ and VIB- on the terminal board to the upper probe signal line, and connect VTX+ and VTX- to the lower probe signal line.



Picture 3.5 Wiring for remote type

4 Display

VFM60 digital vortex flowmeter provide local display and setting, can display several variables on the local multi-functional LCD display. The convertor also has 3 buttons so clients can do setting on it.

4.1 Instruction of multi-functional LCD display

VFM60 digital vortex flowmeter has a display to indicate “Frequency” “Flow rate” “Total flow”. The VFM60 multi-variable version or a standard VFM60 working with RTD and pressure transmitter can also indicate other variables such as “Temperature” “Pressure” “Density” “Mass flow” etc. Please reference to picture 4.1 below.




Picture 4.1 LCD display

The LCD display has 2 areas to display the content, the upper row, the lower row. The upper row displays the flow rate/mass flow/standard flow rate. Below the upper row shows the unit of the variable displayed in upper row.


The lower row display indicates other variables, such as frequency/ pressure/ temperature/ density/ total flow/ velocity. And below the lower row shows the unit of the variable displayed in lower row.

Please reference to picture 4.2 for display



Picture 4.2 Flow rate and total flow

VFM60 multi-variable version or normal version with temperature and pressure compensation, can calculate and display the mass flow of steam, both saturated steam and superheated steam. Please reference to picture 4.3 for mass flow rate displaying.



Picture 4.3 Mass flow and total flow of steam displaying

VFM60 multi-variable version or normal version with temperature and pressure compensation can display variables such as temperature/ pressure/ density. Use the switch button to switch to next variable and it will display for 30 seconds.

Please reference to picture 4.4 as a sample of temperature displaying. You can also keep the lower row consistently display a variable by setting. The default variable displayed in lower row is total flow.



Picture 4.4 lower row is displaying temperature

You can also set the lower row to display several variables in circular turn.

4.2 Unit of the variable displayed

The variables that can be displayed in lower row and their units that can be displayed are as the chart 4.1 below.


Subject	Variable	Unit	Circular display code
TOTAL	Total flow	$N m^3, m^3, L, kg$ or t	01
TEMP	Temperature	$^{\circ}C$	02
PRESS	Pressure	MPa or kPa	03
FREQ	Frequency	Hz	04
DENS	Density	Kg/m^3	05

Chart 4.1 The displayed units

Remark: Clients can select

4.3 Three button setting

VFM60 series digital vortex flowmeter has three buttons on the top of the displayer, which are:  (will be mentioned as “L-R button” below),  (will be mentioned as “U-D button” below),  (will be mentioned as “Enter button” below). Please reference to below picture



Picture 4.5 buttons

When under working, use “U-D button” to switch the displaying content, use “L-R button” can switch to the left and right digits of total flow. “Enter button” is to display the entire digits of total flow directly.

When the flowmeter is under setting mold, the “L-R button” means move to left and right to select the digit, the “U-D button” means to set the digit to a number, the “Enter button” means “confirm”. All the “Digital setting” and “Code setting” of VFM series vortex flowmeter is made through these 3 buttons. Please reference to related article for details

4.4 Total flow displaying

VFM60 can display 9 digits left to decimal point and 3 digits right to it. When the there is more than six digits, the total flow reading will be displayed in two times. One time displays the right digits and the other displays the left digits. You can use the “L-R button” to switch between the right digits and left digits. The left digits will be displayed with a mark of “x1000”. Please reference to picture 4.6



Picture 4.6 Displaying the left digits, a “x1000” mark is displayed

If you want to check the right digits now, please pressure the “L-R button”, the display will be as picture 4.7 below.



Picture 4.7 Display the right digits

According to picture 4.6 and 4.7, the total flow is 569864.581 kg.

4.5 Status

VFM60 series vortex flowmeter has three different statuses as below

- ☐ Working status
- ☐ Setting status
- ☐ Calibration status

When under working status, please follow the instruction in 4.1 to switch the parameter displayed.

When under setting status, you can set the flowmeter, while the flowmeter is still processing, so setting will not have effect on the measuring. In next chapter, there will be instruction of how to do setting.

The calibration of the flowmeter has been finished in manufacture's lab before delivery, including temperature and pressure calibration and the setting of high-limit and low-limit of 4~20mA stimulation output. Thus, customers do not to set any more.


5 Setting

Note: Every VFM60 digital vortex flowmeters has been set according to requirement before delivery, please do not change setting unless it is necessary and under correct instruction!

VFM60 series digital vortex flowmeter has digital setting and code setting. Use code setting to set parameters such as fluid type, compensation type and output signal. Use digital setting to set parameters related to a number, such as pipe size, flow range, factor.


5.1 Code setting

Under working status, to enter code setting, please hold "Enter button" then press "U-D button" at the same time. Please reference to picture 5.1.



Picture 5.1 enter and quit code setting

When in code setting, the first row will display the reference number for the code setting, and the lower row will display the contents of this parameter. The digit that is flashing is the digit under setting. Please reference to picture 5.2, which means C01=02, means fluid type is liquid.




Picture 5.2 code setting

When under code setting, now user can use “L-R button” to choose which digit on the display are to be set, and use “R-D button” to switch the digit to 0-9. The first time of pressing “Enter button” means to set the lower row. Press “Enter button” again to check if the setting is available. If setting is available, the setting made will be canceled and the display will not flash, then press “L-R button” or “U-D button” to set again. When display is not flashing, press “Enter button” to save and go to next setting.

If want to quit code setting, same as entering, please hold “Enter button” then press “U-D button” at the same time.

5.2 Digital setting

Under working status, to enter code setting, please hold “Enter button” then press “L-R button” at the same time. Please reference to picture 5.3.



Picture 5.3 Enter or quit digital setting

When in digital setting, the first row will display the reference number of the digital setting, and the lower row will display the contents of this parameter. The digit that is flashing is the digit under setting. Please reference to picture 5.4., which means D001=1.60000, max pressure is 1.6 (unit according to other setting.)



Picture 5.4 digital setting

When under digital setting, Now, user can use “L-R button” to choose which digit on the displayer are to be set, and use “R-D button” to switch the digit to 0~9 . The first time of pressing “Enter button” means to set the lower row. Press “Enter button” again to check if the setting is available. If setting is available, the setting made will be canceled and the display will not flash, then press “L-R button” or “U-D button” to set again. When display is not flashing, press “Enter button” to save and go to next setting.

If want to quit code setting, same as entering, please hold “Enter button” then press “U-D button” at the same time.

5.3 Setting list

Please check chart 5.1 and 5.2 for code and digital setting address list.

Chart 5.1 Code setting address

Code setting address	Item	Code	Description of code
01	Fluid	00	Steam
		01	Gas
		02	Liquid
02	Density compensation	00	Volume flow display, no density compensation
		01	Density preset
		02	Pressure compensation (for saturated steam pressure not larger than 20Mpa)
		03	Temperature compensation (For saturated steam)
		04	Temperature and pressure compensation (For superheated steam)
		05	$\rho=A+BP$ (Pressure compensation)
		06	$\rho=A+BT$ (Temperature compensation)
		07	AGA-NX-19 to calculate compressibility factor
		08	Temperature and pressure compensation to get normal condition flow rate of gas
		09	AGA-8 to calculate compressibility factor
		10	Air compressor output flow analysis
		11	Mass flow(Standard volume*standard density)
05	Output	01	Pulse (Please reference to D008 for K factor)
		02	4~20mA or HART@4~20mA
		03	200-1000HZ frequency output, set what to output in C06
		04	frequency output for total flow, set factor in D013
06	4~20mA or 4~20mA@HART or 200-1000Hz output parameter	00	Flow rate
		01	Temperature
		02	Pressure
07	Damping	01~99	1~99 seconds
08	Instrument number	00~99	For Modbus
		00~15	For Modbus or HART communication
09	Baud rate	01	1200 no parity 1 stop bit
		02	1200 even parity 1 stop bit
		03	2400 no parity 1 stop bit
		04	2400 even parity 1 stop bit

		05	4800 no parity 1 stop bit
		06	4800 even parity 1 stop bit
		07	9600 no parity 1 stop bit
		08	9600 even parity 1 stop bit
		09	19200 no parity 1 stop bit
		10	19200 even parity 1 stop bit
		11	1200 odd parity 1 stop bit
		12	2400 odd parity 1 stop bit
		13	4800 odd parity 1 stop bit
		14	9600 odd parity 1 stop bit
		15	19200 odd parity 1 stop bit
		16	38400 no parity 1 stop bit
		17	38400 even parity 1 stop bit
		18	38400 odd parity 1 stop bit
		19	57600 no parity 1 stop bit
		20	57600 even parity 1 stop bit
		21	57600 odd parity 1 stop bit
		22	115200 no parity 1 stop bit
		23	115200 even parity 1 stop bit
		24	115200 odd parity 1 stop bit
10	Time unit for flow rate	00	/s
		01	/min
		02	/h
		03	/day
11	Mass unit	01	kg
		02	ton
		03	lb
12	Volume unit for flow rate	01	m ³
		02	L
		03	ft ³
		04	US gal
		05	UK gal
		06	bbl
13	Pressure unit	01	Mpa
		02	Kpa
		03	Psi
		04	Bar
		05	Mpa (G)
		06	Kpa (G)
		07	Psi (G)
		08	Bar (G)

Code setting address	Item	Code	Description of code
14	Temperature unit	01	°C
		02	°F
		03	K
15	Right digits number for total flow	00~05	00: No right digits for total flow
		01~05	1~5 right digits for total flow
16	1st row display parameter	01	Flow rate
		02	percentage of flow rate to flow range
17	lower row display parameter	00	No display
		01	Total flow
		02	Temperature
		03	Pressure
		04	Density
		05	Frequency
18	Density unit	01	Kg/m3
		02	lb/ft3
19	Decimal of flow rate	00~04	00: No right digits for flow rate
		01~04	1~4 right digits for flow rate
20	Decimal of temperature	00~04	00: No right digits for temperature
		01~04	1~4 right digits for flow rate
21	Decimal of pressure	00~04	00: No right digits for pressure
		01~04	1~4 right digits for pressure
30	Time space for circle display	00~30	00: circle display off
			1~30: 1~30 seconds between the display of different parameter
31	First parameter displayed in circle display	00~05	00: circle display off
			01~05: see chart 4.1
⋮	⋮	⋮	
35	Last parameter displayed in circle display	00~05	Same as above
38	Sequence of float (under RS485 communication)	01	LL_LH_HL_HH
		02	HH_HL_LH_LL
		03	LH_LL_HH_HL
		04	HL_HH_LL_LH
47	Password function	00	off
		01	on
48	Set password	00	Keep the password
		01	Change the pass word
49	Spectrum analyzing checking	00	Working status
		12	spectrum analyzing checking

50	Total flow reset	00	Reset total flow to 0
		01	Default
55	Times of over total flow	00~99	For reading only
60	Restore to backup date	06	Restore to backup date
61	Save setting backup	16	Save current setting for backup

Note:

1) If the unit of flow rate is changed or measurement changed from flow rate to mass flow, users can reset the total flow to 0 or record the current total flow

2) Total flow=(time of over total flow)* (max display of total flow)+(current total flow reading)

Chart 5.2 Digits setting address

Digital setting address	Item	Code	Description of code
001	Max pressure	[-99999, 999999]	Max input/output pressure
002	Min pressure	[-99999, 999999]	Min input/output pressure
003	Max temperature	[-99999, 999999]	Max input/output temperature
004	Min temperature	[-99999, 999999]	Min input/output temperature
005	Preset density	(0, 999999]	When C02=01, the meter will use this density, unit according to setting
008	K factor	(0, 999999]	K factor according to calibration result, unit is pulses/Litre. Flow=3.6*freq/K
009	Max flow rate	(0, 999999]	unit is same as flow rate, Max/min flow rate of 4~20mA and 200~1000Hz output
010	Min flow rate	[0, 999999]	
011	Max frequency	[0, 999999]	Up-limit of frequency (Hz) output
012	Min frequency	[0, 999999]	Down-limit of frequency (Hz) output
013	pulse factor for total flow	(0, 999999]	used when freq output of total flow
014	Ambient pressure	(0, 999999]	Unit according to setting
015	Pipe size	(0, 999999]	unit is mm
021	Cut off small signal	[0, 999999]	unit is Hz
022	Standard temperature	[0, 999999]	unit is ° C; for standard flow rate calculation
023	Temperature of air compressor inlet	[-40, 999999]	Unit is ° C, for air compressor flow outlet analysis
024	Pressure of air compressor inlet	(0, 999999]	Unit is Mpa, for air compressor flow outlet analysis

025	Temperature preset	[-99999,999999]	Unit is ° C
026	Resonance frequency starting frequency	(0, 999999]	For high speed steam measure use
027	Resonance frequency ending frequency	(0, 999999]	For high speed steam measure use
030	Relative density of compressibility factor	[0.55, 0.90]	For calculation of compressibility factor of natural gas
031	mol% of N2 and H2	[0, 0.1]	For calculation of compressibility factor of natural gas, eg.if 1%, please input 0.01
032	mol% of CO2	[0, 0.3]	For calculation of compressibility factor of natural gas, eg.if 1%, please input 0.01
033	Higher heating value	[20, 48]	MJ/mol, For calculation of compressibility factor of natural gas

Note:

Max freq output=10KHz, the pulse factor for total flow should be set properly set according to the current total flow.

5.4 Example of setting

Sample: For vortex flowmeter VFM60, measure gas in DN50 pipe, K factor= 7.802P/L, density preset, mass flow display unit is kg/h. 4~20mA output with a flow range of 0~4000kg/hr


	Address	Code	Description
Code setting	01	01	gas
	02	01	Density preset
	05	02	4~20mA analog output
Digital setting	005	2.0000	Density=2
	008	7. 802	K factor=7.802 P/L
	009	4000	Flow rate of 20mA
	010	0	Flow rate of 4mA
	015	50	Pipe size=50mm

6 Password

6.1 Turn on the password function


There is no password set in default in a new VFM60 digital vortex flowmeter, users can set a password following instruction below.

Enter code setting, set C47=01, confirm and quit then enter the password setting interface as picture 6.1



Picture 6.1 Password setting interface

To set a new password, users must input the correct password twice, the password will become effective only if the both inputs are the same; or users have to input again. If the power is off during a password setting process, the password will be 2000 as default. When a password becomes effective, users have to input the correct password before he can set the flowmeter, please reference to picture 6.2. If users input incorrect password 3 times consistently, the display will come back to normal display



Picture 6.2 Password input

6.2 Change the password

If a password has been set to a VFM60 vortex flowmeter, users can enter code setting C48=01 to set a new password. The process of setting is same with 6.1.1.

7 Instruction of RS485 Modbus Communication

7.1 Interface regulation

- ☐ The communication interface should be RS485, the range of Baud rate should be 1200~115200.
- ☐ The wiring terminal is “A” and “B”.
- ☐ The communication should comply with MODBUS-RTU statute.

The combination of a communication signal: Address code - function code – date segment – CRC calibration code. The distance between two characters should not be longer than one character, or it will be considered as the beginning of a new message or the end of a old message. The message is combined with hexadecimal arrays.

- ☐ Definition of the data: Please reference to the chart 7.1 below.

Chart 7.1 Address of the displayed data

Register address	Usage	Nature	Data type
0~1	Flow rate	Read only	Float
2~3	Frequency	Read only	Float
4~5	Reserved	Read only	Float
6~7	Pressure	Read only	Float
8~9	Temperature	Read only	Float
10~11	Density	Read only	Float
24~25	Total flow	Read only	Float

The displayable data including flow rate, frequency, pressure, temperature, density and total flow, if the meter do not have density compensation, then the reading of pressure and temperature will both be 0. The date of the parameters in above chart can be read by using function code 03 according to the address above and shifting.

The address of code setting is as below.

Chart 7.2 Address of code setting

Register	Usage	Range	Nature	Data type
1000	Fluid type C01	1~2	Read only	Short
1001	Density compensation C02	0~9	Read	Short
1004	Output C05	1~4	Read	Short
1005	200~1000 00Hz output parameter C06	1~3	Read	Short
1006	Damping C07	1~99	Read	Short
1007	Instrument number C08	Hart (0~15) ModBus (1~99)	Read	Short
1008	Baud rate C09	1~24	Read	Short
1009	Unit of time C10	0~2	Read	Short
1010	Mass unit C11	1~3	Read	Short
1011	Volume unit C12	1~5	Read	Short
1012	Pressure unit C13	1~4	Read	Short
1013	Temperature unit C14	1~3	Read	Short
1014	Right digits number for total flow C15	0~5	Read	Short
1015	1st row display parameter C16	1~2	Read	Short
1016	lower row display parameter C17	0~5	Read	Short
1017	Density unit C18	1~2	Read	Short
1029	Time space for circle display C30	0~30	Read	Short
1030	First parameter displayed in circle display C31	0~5	Read	Short
1031	Second parameter displayed in circle display C32	0~5	Read	Short
1032	Third parameter displayed in circle display C33	0~5	Read	Short
1033	Fourth parameter displayed in circle display C34	0~5	Read	Short
1034	fifth parameter displayed in circle display C35	0~5	Read	Short
1035	C36	0~5	Read	Short

1036	C37	0~1	Read	Short
1037	Sequence of float C38	1~4	Read	Short
1046	Password function C47	0~1	Read	Short
1047	Set password C48	0~1	Read	Short
1048	Spectrum analyzing checking C49	0~12	Read	Short
1049	Total flow reset to 0 C50	0~1	Read	Short
1050	C51	0~99	Read	Short
1051	C52	0~0	Read	Short
1052	C53	0~0	Read	Short
1053	C54	0~0	Read	Short
1054	Times of over total flow C55	0~99	Read	Short
1059	Restore to backup date C60	0~99	Read	Short
1060	Save setting backup C61	0~99	Read	Short

Users can use function code 04 and 06 to access to the address for code setting above.

Digital setting address is as below

Chart 7.3 Address of digital setting

Register	Usage	Range	Nature	Data type
2000~2001	D001 Max pressure	-1e5 ~1e6	Read	Float
2002~2003	D002 Min pressure	-1e5 ~1e6	Read	Float
2004~2005	D003 Max temperature	-1e5 ~1e6	Read	Float
2006~2007	D004 Max temperature	-1e5 ~1e6	Read	Float
2008~2009	D005 Density	0~1e6	Read	Float
2014~2015	D008 K factor	0~1e6	Read	Float
2016~2017	D009 Max flow rate	0~1e6	Read	Float
2018~2019	D010 Min flow rate	0~1e6	Read	Float
2024~2025	D013 Factor for total flow output	0~1e6	Read	Float
2026~2027	D014 Ambient pressure	0~1e6	Read	Float
2028~2029	D015 Pipe size	0~1e6	Read	Float
2040~2041	D021 Cut off small signal	0~1e6	Read	Float
2058~2059	D030 Specific density	[0.55, 0.90]	Read	Float
2060~2061	D031 mol% of N2 and H2	[0, 0.1]	Read	Float
2062~2063	D032 mol% of CO2	[0, 0.3]	Read	Float
2064~2065	D033 Higher heating value	[20, 4 8]	Read	Float

The chart above indicates the register address, usage of the register, restriction of modification, read/write nature and data type. The register above is all holding register, the supporting function code is 03,04,06,16 function code.

7.2 Commends

Function code 03 – Read register

Request	Response
01 : Address	01: Address
03 : Function code	03 : Function code
00 : Register address higher	04 : Quantity of bit
00 : Register address lower (display the address)	80 : Data 1
00 : Register number higher	04 : Data 2
02 : Register number lower	80 : Data 3
CRCH: CRC parity code higher	80 : Data 4
CRCL : CRC parity code lower	CRCH: CRC Parity code higher
	CRCL : CRC parity code lower

Note: To read a float date, the quantity of the register address and its value have to be even, or reponse will be error.

7.3 Calculation of CRC parity code.

Request	Response
01 : Address	N1 CRC=0FFFFH is initial value
10 : Function code	N2 XOR operation the CRCL and N1
00 : Register address higher	N3 CRC move 1 bit right , if move out is 1 bit
01 : Register address lower	N4 CRC=CRC XOR A001H
00 : Register quantity higher	N5 if move out is 0 , CRC=CRC
04 : Register quantity lower	N6 Move right for 8 times to finish the N1 calculation
04 : Data quantity	N7 ...
80 : Data 1	N8 XOR operation the CRCL and N11
04 : Data 2	N9 CRC move 1 bit right , if move out is 1 bit
80 : Data 3	N10 CRC=CRC XOR A001H
80 : Data 4	N11 if move out is 0 , CRC=CRC
CRCH : CRC Parity code higher	Move right for 8 times to finish the N11 calculation
CRCL : CRC Parity code lower	Get the CRC calibration value

7.4 The float data format of the instrument

The storage sequence of 4 bits float format is as below:

Address: 0 1 2 3

Content: M M M M M M M M M M M M M M M M E M M M M M M M S E E E E E E E E

Use IEEE standard method, do not store 1 on top digit, if top digit is 1, means negative; if top digit is 0, means positive. So the 23 mantissas and a 1 on top digit, which is concealed, constitute a 24 bits fixed point true form decimal, which is a decimal have mantissas less than 1 and more than or equal to 0.5.

The lowest 8 bits are exponent-marker using shift code method. The exponent marker equals to the actual value minus 127. For example: 7=86H-7FH, -10=75H-7FH

e.g.: 100=0x00,0x00,0x42,0xc8

-100=0x00,0x00, 0xc2,0xc8

0=0x00.0x00.0x00.0x00 (exponent-marker is 0, the number is 0)

7.5 The sequence of the float data bytes of instrument

Code setting C38 is used for setting the sequence of the float date bytes of instrument.

Float date will occupy 4 bytes (2 registers). To set the bytes order of float date, please modify register:

1: LL_LH_HL_HH the lower 16 bytes registers come first, the lower 8 bytes within the 16 bytes registers come first.

eg: 100=0x00,0x00, 0xc8, 0x42

-100=0x00,0x00,0xc8,0xc2

2: HH_HL_LH_LL the higher 16 bytes registers come first, the higher 8 bytes within the 16 bytes registers come first.

eg: 100=0x42,0xc8,0x00,0x00

-100=0xc2,0xc8 ,0x00,0x00

3: LH_LL_HH_HL the lower 16 bytes registers come first, the higher 8 bytes within the 16 bytes registers come first.

eg: 100=0x00,0x00,0x42,0xc8

-100=0x00,0x00,0xc2,0xc8

4: HL_HH_LL_LH the higher 16 bytes registers come first, the lower 8 bytes within the 16 bytes registers come first.

eg: 100=0xc8,0x42,0x00,0x00

-100=0xc8,0xc2,0x00,0x00

7.6 Modbus error response

When the host sends a command and asks for a correct response, one of below four is going to happen:

- (1) If the command from the host is correct and processable, the flowmeter will give a correct response.
- (2) If the flowmeter does not receive the request message due to a communication error, the flowmeter will not return a response message, and the host program will eventually process the request timeout.
- (3) If the flowmeter received a command, but detected parity, the error of LRC and CRC will cause no response. The host will process an overtime commend.

- (4) If the flowmeter receives the request message without communication errors, but cannot query and process (read or write non-existent registers, etc.), the flowmeter will return an abnormal response message.

An error response has two bytes sections to show its difference from a correct response.

Function code section: In a correct response, the flowmeter will copy the origin function code sent from the host, and the highest bytes of them are all 0(all function codes are smaller than 0x80). In an error response, the flowmeter will set the highest bytes to 1. The host can detect the error code and know the content of the error when it detects that the highest bytes of function codes are 1.

Value section: In an error response, the flowmeter will reply a byte as the error code to definite the content of the error. Please reference to the chart below for the error codes and its definition:

Code	Name	Meaning
01	Illegal function code	Flowmeter can not process the function code in a command. Maybe this function code can only be used on a new device, or it can also indicate that the flowmeter is under error statues.
02	Illegal address	The flowmeter can not process with the address in the command. The initiate address plus address diversion are higher than the highest address.
03	Illegal contents of value	The content of the value in the command is not acceptable for the flowmeter.
04	Flowmeter function failed	An unrecoverable failure happened when the flowmeter is trying to response.
05	Response	The flow meter will take a long while to process the command. So response this error code to prevent the host from processing an overtime command.
06	Flowmeter is busy	To advise the host that the flowmeter is processing a command which will takes a long time. So the host should resend the command when the flowmeter is free.

7.7 Examples of communication

The flowmeter's instrument Modbus address is 05, baud rate=9600 (C08=05, C09=07, C38=03).

Example 1: Read flow rate F,F=916.49 (4 bytes float)

Host command: 05 03 00 00 00 02 C5 8F

Flowmeter response: 05 03 04 1F 5C 44 65 8B 1E

Example 2: Read total flow

Host command: 05 03 00 18 00 02 45 88

Flowmeter response: 05 03 04 1E 3F 44 9D 7b 7E (total flow in float =1256.94)

Example 3: Read all the value displayed on the flowmeter, including flow rate, frequency, pressure, temperature, density, total flow all together 13 value (52 bytes)

Host command: 05 03 00 00 00 1A c5 85

Flowmeter response: 05 03 34

1F 5C 44 65 (flow rate=916.49)

00 00 42 48 (frequency=50)

00 00 00 00 (reserved=0)

00 00 00 00 (pressure=0)

00 00 00 00 (temperature=0)

00 00 3F 80 (density=1.00)

00 00 00 00 (reserved)

00 00 00 00 (reserved)

00 00 00 00 (reserved)

00 00 00 00 (reserved)

00 00 00 00 (reserved)

00 00 00 00 (reserved)

00 00 04 E8 (reserved=1256)

00 00 00 00 (reserved=0)

1E 3F 44 9D (total flow in float=1256.94)

9E (CRCL)

4C (CRCH)

8 Introduction of HART communication protocol

8.1 HART commands

8.1.1 Command 0: Read transmitter unique identifier

Command format

Return to the expansion device type code, version number and identification number

Request: None

Response:

Byte 0:	254
Byte 1:	Manufacture's ID
Byte 2:	Manufacture's device type
Byte 3:	Number of request preambles
Byte 4:	Revision level of universal command
Byte 5:	Revision level of transmitter document
Byte 6:	Software revision level
Byte 7:	Hardware revision level
Byte 8:	Flags, none defined at this time
Byte 9-11:	Device identification Number

Test of command

Send 0 command:FF FF FF FF FF 02 80 00 00 82; to request information of the instrument

Receive 0 command:FF FF FF FF FF 06 80 00 0E 00 00 FE 1A 1A 05 05 00 00 00 00 AD 18 8C 4F

8.1.2 Command 1: Read primary variable value (PV)

Command format:

Return to primary variable value in float.

Request: None

Response:

Byte 0: Primary variable unit code

Byte 1-4: Primary variable

Remark: The unit code is 75:kg/hour, 19:m3/hour.

Set primary command to flow rate.

Test of command:

Send command 1: FF FF FF FF FF 82 9A 1A AD 18 8C 01 00 3A ;to read the IEEE754 float value of primary variable.

Receive command 1:FF FF FF FF FF 86 9A 1A AD 18 8C 01 07 00 00 13 00 00 00 00 2A

8.1.3 Command 2:Read primary variable's current and percentage value

Command format:

Read the current and percent of the primary variable, the current of primary variable always match the AO current output of the instrument. Percent is not restricted within 0~100%, if it is beyond the limit of primary variable, it will find the limit of the transmitter.

Request: None

Response:

Byte 0-3: Analog output current mA, IEEE754

Byte 4-7: Percent of range, IEEE 754.

Test of command:

Send command 2: FF FF FF FF FF 82 9A 1A AD 18 8C 02 00 39; to read the current and primary variable percent of range.

Receive command 2: FF FF FF FF FF 86 9A 1A AD 18 8C 02 0A 00 00 40 80 00 00 00 00 00 00 F7

8.1.4 Command 3:Read primary variable current and dynamic variables

Command format:

Read the current of primary variable and 4 preset dynamic variables at maximum. The current of primary variable always match the AO output current of the instrument. Every type of device has a definition on a relative dynamic variable, for example the secondary variable is temperature sensor.

Request: None

Response:

Byte 0-3: Analog output current mA, IEEE 754

Byte 4: Primary variable unit code

Byte 5-8: Primary variable, IEEE 754

Byte 9: Secondary variable unit code

Byte 10-13: Secondary variable, IEEE 754

Byte 14: Tertiary variable unit code

Byte 15-18: Tertiary variable, IEEE 754

Byte 19: Quaternary variable unit code

Byte 20-23: Quaternary variable, IEEE 754

Remark: Primary variable is flow rate. The unit code is 75:kg/hour, 19:m3/hour;

Secondary variable is total flow. The unit code is 61:kg, 43:m3;

Tertiary variable is frequency. The unit is Hz;

Quaternary variable is temperature. The unit is 32: °C;

Test of command:

Send command 3:FF FF FF FF FF 82 9A 1A AD 18 8C 03 00 38; to read dynamic variables

Receive command 3:FF FF FF FF FF 86 9A 1A AD 18 8C 03 1A 00 00 40 80 00 00 13 00 00 00 00 2B 48 33 5A 4B 26 00 00 00 00 20 00 00 00 00 B2

8.1.5 Command 6:Write polling address

Command format:

It is a date link management command. This command writes a polling address to the device. This address is used to control the AO of primary variable and providing of device ID.

Only when the polling address of the instrument is 0, that the AO output of primary variable is available. If the address is 1~15, AO will be not activated and will not response, AO will be minimum value; transmission status will be the 3rd statue-----primary variable AO fixed; max and min alarm not implemented. If polling address is write back to 0, AO will be activated again and will response.

Request:

Byte 0: Device polling address

Response:

Byte 0: Device polling address

Test of command:

Send command 6:FF FF FF FF FF 82 9A 1A AD 18 8C 06 01 00 3C ; to write POLLING ADDRESS

Receive command 6:FF FF FF FF FF 86 9A 1A AD 18 8C 06 03 00 00 00 3A

8.1.6 Command 11:Read unique identifier associated with tag

Command format:

It is a data link management command. This command will return the device type, revision level and device identification number of the device which matches to the tag. Process the command upon receipt of the expansion address or broadcast address. The expansion addresses in command and response are the same.

Request:

Byte 0-5: Tag,Packed ASCII

Response:

Byte 0: Device type code for expansion

Byte 1: Manufacture identification code

Byte 2: Manufacture device type

Byte 3: Number of request preambles

Byte 4: Revision level of universal command

Byte 5: Revision level of transmitter document

Byte 6: Software revision level

Byte 7: Hardware revision level

Byte 8: Flags, none defined at this time.

Byte 9-11: Device identification number

Test of command:

Send command 11: FF FF FF FF FF 82 9A 1A AD 18 8C 0B 00 30 ; Read relevant info of the device such as unique identifier associated with tag

Receive command 11: FF FF FF FF FF 86 9A 1A AD 18 8C 0B 0E 00 00 FE 1A 1A 05 05 00 00 00 00 AD 18 8C FD

8.1.7 Command 12:Read message

Command format:

To read message

Request: None

Response:

Byte 0-23: Message

Test of command:

Send command 12:FF FF FF FF FF 82 9A 1A AD 18 8C 0C 00 37 ; read message

Receive command 12:FF FF FF FF FF 86 9A 1A AD 18 8C 0C 1A 00 00 59 00 74 D6 05 8F 49 41
58 80 42 47 25 40 4C 81 04 8F 0C 54 D3 3D 28 20 10

8.1.8 Command 13:Read tag, descriptor, date**Command format:**

Read device tag,description and date.

Request: None

Response:

Byte 0-5: Tag,ASCII

Byte 6-17: Descriptor,ASCII

Byte 18-20: Date: day,month,year

Test of command:

Send command 13:FF FF FF FF FF 82 9A 1A AD 18 8C 0D 00 36 ;read device tag, descriptor and date

Receive command 13:FF FF FF FF FF 86 9A 1A AD 18 8C 0D 17 00 00 50 11 E0 82 08 20 58 F4
94 15 88 06 30 F5 CD 15 41 52 0F 01 6F E2

8.1.9 Command 14: Read primary variable sensor information: device serial number and limits**Command format:**

Read device information

Request: None

Response:

Byte 0-2: Sensor serial number MSB, 24-BIT unsigned integer

Byte 3: Flow rate unit

Byte 4-7: Upper sensor limit of flow rate

Byte 8-11: Lower sensor limit of flow rate

Byte 12-15: Minimum span of flow rate

Test of command:

Send command 14: FF FF FF FF FF 82 9A 1A AD 18 8C 0E 00 35; to read primary sensor serial number and limits.

Receive command 14: FF FF FF FF FF 86 9A 1A AD 18 8C 0E 12 00 00 00 00 00 13 43 96 00 00
00 00 00 00 38 D1 B7 17 AC

8.1.10 Command 15: Read primary variable output information**Command format:**

Read Primary variable alarm select code, primary variable transfer code, primary variable range values units code, primary variable upper and lower range value, primary variable damping value, write protect code and private label distributor code VIII

Request: None

Response:

Byte0: Alarm select code

Byte1: Primary variable transfer function code

Byte2: Primary variable range values unit code

Byte3-6: Primary variable upper range value, IEEE754

Byte7-10: Primary variable lower range value, IEEE754

Byte11-14: Primary variable damping value, IEEE754, units of seconds

Byte15: Write protect code

Byte16: Private Label Distributor Code

Test of command:

Send command 15: FF FF FF FF FF 82 9A 1A AD 18 8C 0F 00 34; Read primary variable output information

Receive command 15: FF FF FF FF FF 86 9A 1A AD 18 8C 0F 13 00 00 00 00 13 43 96 00 00 00 00 00 42 20 00 00 FB 12 6E

8.1.11 Command 16: Read final assembly number**Command format:**

Read final assembly number.

Request: None

Response:

Byte 0-2: Final assembly number

Test of command:

Send command 16: FF FF FF FF FF 82 9A 1A AD 18 8C 10 00 2B; Read final assembly number

Receive command 16: FF FF FF FF FF 86 9A 1A AD 18 8C 10 05 00 00 A8 36 81 35

8.1.12 Command 17: Write message**Command format:**

Write message

Request:

Byte 0-23: Message

Response:

Byte 0-23: Message

Test of command:

Send command 17:FF FF FF FF FF 82 9A 1A AD 18 8C 11 18 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10 11 12 13 14 15 16 17 32 ;message

Receive command 17:FF FF FF FF FF 86 9A 1A AD 18 8C 11 1A 00 00 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10 11 12 13 14 15 16 17 34

8.1.13 Command 18: Write tag, descriptor, date

Command format:

Write tag, descriptor, date.

Request:

Byte 0-5: Tag,ASCII

Byte 6-17: Descriptor,ASCII

Byte 18-20: Date: day, month, year

Response:

Byte 0-5: Tag,ASCII

Byte 6-17: Descriptor,ASCII

Byte 18-20: Date: day, month, year

Test of command:

Send command 18: FF FF FF FF FF 82 9A 1A AD 18 8C 12 15 00 3C

Receive command 18:FF FF FF FF FF 86 9A 1A AD 18 8C 12 17 00 3A

8.1.14 Command 19: Write final assembly number

Command format:

Write final assembly number

Request:

Byte 0-2: Final assembly number

Response:

Byte 0-2: Final assembly number

Test of command:

Send command 19: FF FF FF FF FF 82 9A 1A AD 18 8C 13 03 01 02 03 2B ;

Receive command 19: FF FF FF FF FF 86 9A 1A AD 18 8C 13 05 00 00 01 02 03 29

8.1.15 Command 34: Write primary variable damping value

Command format:

Write primary variable damping value. If value is not acceptable, will revert with alarm.

Request:

Byte 0-3: Damping value, IEEE754

Response:

Byte 0-3: Actual damping value, IEEE754

Test of command:

Send command 34: FF FF FF FF FF 82 9A 1A AD 18 8C 22 04 40 00 00 00 5D; Write primary variable damping value

Receive command 34: FF FF FF FF FF 86 9A 1A AD 18 8C 22 06 00 00 40 00 00 00 5B

8.1.16 Command 35: Write primary variable range values

Command format:

The upper and lower limits of primary variable are independent. The primary variable range unit value that this command received has no effect on the primary variable unit value. The primary value range value will be returned in the unit received.

Most device allows that the measurement range upper limit lower than lower limit ,to support the device to reverse output.

Request:

Byte 0: Primary variable upper and lower range value unit code

Byte 1-4: Primary variable upper range limit, IEEE 754

Byte 5-8: Primary variable lower range limit, IEEE 754

Response:

Byte 0: Primary variable upper and lower range value unit code

Byte 1-4: Primary variable upper range limit, IEEE 754

Byte 5-8: Primary variable lower range limit, IEEE 754

Test of command:

Send command 35: FF FF FF FF FF 82 9A 1A AD 18 8C 23 09 13 40 00 00 00 40 00 00 00 02;
Write primary variable range values

Receive command 35: FF FF FF FF FF 86 9A 1A AD 18 8C 23 0B 00 00 13 00 00 00 00 00 00 00
00 04

8.1.17 Command 36: Write primary variable upper limit value

Command format:

Write the primary variable upper limit to current primary variable value. The change of primary variable upper limit value has no effect on the primary variable lower limit.

Request:

NONE

Response:

NONE

Test of command:

Send command 36: FF FF FF FF FF 82 9A 1A AD 18 8C 24 00 1F; Write the primary variable upper limit to current primary variable value.

Receive command 36: FF FF FF FF FF 86 9A 1A AD 18 8C 24 02 00 00 19

8.1.18 Command 37: Write primary variable lower limit value

Command format:

Write the primary variable lower limit to current primary variable value. The change of primary variable lower limit value has no effect on the primary variable higher limit.

Request:

NONE

Response:

NONE

Test of command:

Send command 37: FF FF FF FF FF 82 9A 1A AD 18 8C 25 00 1E; Write the primary variable lower limit to current primary variable value.

Receive command 37: FF FF FF FF FF 86 9A 1A AD 18 8C 25 02 00 00 18

8.1.19 Command 40: Enter/Exit primary variable current mode

Command format:

Device is set to fixed primary variable current, when primary variable is 0, means to exit primary variable current mode.

Request:

Byte 0-3: Fixed primary variable current level IEEE 754, mA

Response:

Byte 0-3: Actual fixed primary variable current level IEEE 754, mA

Test of command:

Send command 40: FF FF FF FF FF 82 9A 1A AD 18 8C 28 04 40 80 00 00 D7

Receive command 40: FF FF FF FF FF 86 9A 1A AD 18 8C 28 06 00 00 40 80 00 00 D1

8.1.20 Command 45: Trim primary variable current DAC zero

Command format:

Trim the primary variable current AO zero, so the current value is accurate set to its min value.

Before implementing this command, use command 40 to set current to accurate primary variable AO min value. If device is not under fixed primary variable current mode or current has not been set to accurate min value, need to return response code 9---not under correct current mode.

Request:

Byte 0-3: Externally measured primary variable current level IEEE754, units of mA

Response:

Byte 0-3: Actual measured primary variable current level IEE 754

Test of command:

Send command 45: FF FF FF FF FF 82 9A 1A AD 18 8C 2 D 04 40 80 00 00 D2

Receive command 45: FF FF FF FF FF 86 9A 1A AD 18 8C 2D 06 09 00 40 80 00 00 DD :
response code is 09, device is not under correct current mode.

8.1.21 Command 46: Trim primary variable current DAC gain

Command format:

Trim primary variable AO gain, so the current value is accurate set to its max value.

Before implementing this command, use command 40 to set current to accurate primary variable AO max value. If device is not under fixed primary variable current mode or current has not been set to accurate max value, need to return response code 9---not under correct current mode.

Request:

Byte 0-3: Externally measured primary variable current level IEEE754, units of mA

Response:

Byte 0-3: Actual measured primary variable current level IEE 754

Test of command:

Send command 46: FF FF FF FF FF 82 9A 1A AD 18 8C 2 E 04 40 80 00 00 D1

Receive command 46: FF FF FF FF FF 86 9A 1A AD 18 8C 2E 06 09 00 40 80 00 00 DE :
response code is 09, device is not under correct current mode.

8.1.22 Command 140: Reset totalizer

Command format:

Reset totalizer

Request:

NONE

Response:

NONE

Test of command:

Send command 140: FF FF FF FF FF 82 9A 1A AD 18 8C 8C 00 B7 Reset totalizer

Receive command 140: FF FF FF FF FF 86 9A 1A AD 18 8C 8C 02 00 00 B1

9 Maintaining


9.1 How to changing the housing orientation

The housing might need to be rotated for better wiring access or improved viewing of the display:

- 1) Loosen the tightening screw as shown in below picture before rotating the transmitter.
- 2) Rotate the housing to the desired orientation.
- 3) Tighten the screw.

Note

Rotating the meter head will increase the cable tension and damage it. It is recommended to rotate it 90°C. If you need to rotate it 180°C, please operate it with caution!




Picture 9.1 rotate the transmitter

9.2 Replace the transmitter circuit board

- 1) Please make sure the power is off before replacing the transmitter.

- 2) Remove the front cover.
- 3) Loose the 4 screws on the circuit boards, then can take the boards out a little.
- 4) Remove all the plugs on the circuit board, then remove the circuit board away
- 5) Put the new circuit board in and put the plug on
- 6) Tighten the 4 screws on the board, tighten the front cover

Please reference to picture 9.2



Picture 9.2 Replace the transmitter\

10 Troubleshooting and repair

10.1 Safety introduction

Please do not open the cover on the flame proof enclosure if in an explosive environment.

When trying to wire to HART or RS485 device, please make sure that the process of wiring the device into the loop complies with the intrinsic safety requirement. Or please process the wiring in a none-explosive environment.

Please make sure the environment the flowmeter in can meet the requirement of the certificate.

When power is wired, please make sure the front and rear cover is closed properly.

10.2 Diagnostic information

Symptom	Reason	Trouble shooting	repair
No display	Power supply failure	Test the voltage on the power source with a universal meter	Re-wire the power or use a new power
	Power is not wired	Test the voltage on the power source with a universal meter	Wire the power
	Cable if broken	Check if there is break off point on the cable	Check the cable and re-wire
	Wrong wiring	Check if wiring to the correct terminal	Re-wire
Displayed flow rate is 0 while there are flow in the pipe	Flow rate is lower than the meter's lower limit	Increase the flow rate to check	Increase the flow rate or replace a new proper flowmeter
	The flow rate of small signal cut off function is too high	Check the small signal cut off setting	Set the small signal cut off to a proper value

	Energy threshold value is too high	Check if the Energy threshold value is too high in spectrum analyzing checking mode	Set the Energy threshold value to a proper value (Please reference to Note 1 for how to set)
	Transmitter function failure	Replace the transmitter with another transmitter of same type to check	Replace the transmitter
	Sensor is damaged	Increase the flow rate to check first, then install the transmitter to another flowmeter in same type to check.	Replace the sensor
	Pipeline blocked or sensor jammed.	If all above possibilities are eliminated, please check the pipe line and installation.	Re-install the flowmeter
The flowmeter has flow reading while there is no flow in the pipe	Power frequency interference	Check the frequency display on meter is stable at the value that same as the power frequency	Re-wire the meter with shielded cable according to requirement.
	There is high voltage instrument or high frequency interference close to the flowmeter	Check if there is high voltage instrument or high frequency interference close to the flowmeter	Re-locate the flowmeter
	There is heavy vibration on the pipe line	Sense the vibration on the pipe line by touch it with hand	Tighten the pipeline where the flowmeter is installed
	Valve is not closed properly that there flow leak into the pipe	Check pressure and check if valve is closed and sealed	Repair the valve
The flow rate reading fluctuate significantly	The gasket and the pipe are not concentric	Check the position of the gasket	Re-install the gasket
	The flowmeter pipe body and the pipe line are not concentric	Check if the flowmeter pipe body and the pipe line are not concentric	Re-install the meter
	Straight pipe length not enough or the inner diameter of flowmeter pipe body do not match the pipeline	Check the straight pipe length and the diameter of the pipeline	Re-locate the flowmeter
	There is heavy vibration on the pipe line	Sense the vibration on the pipe line by touch it with hand	Tighten the pipeline where the flowmeter is installed
	The fluid has not fill the pipeline fully	Check the fluid status and the location of the meter.	Re-locate the flowmeter
	Two phase flow	Check if there is 2-phase flow according to the pressure and temperature of the fluid.	If the fluid is liquid-solid two phases flow, need to install a filter at upstream of the flow meter. If the fluid is liquid-gas two phase flow, need to install a getter at upstream of the flow meter.
	Transmitter failure	Replace the transmitter with another transmitter of same type to check	Replace the transmitter
There is big difference between the flow reading and the process flow rate	No density compensation for steam measurement	Check the density compensation devices and the setting	Fix density compensation
	The estimated flow rate before using the meter is wrong	Use other flowmeter to confirm the actual flow rate	

	Setting incorrect	Check the settings of meter K factor, upper and lower limit of flow rate	Set the meter correctly
--	-------------------	--	-------------------------

Note 1: Enter code setting, set C49=12. Press “U-D button” to check the current energy of vortex flow signal and vibration signal. E1 is the energy of vortex flow signal, please set the energy threshold value lower than the displayed value. E.1 is the energy of vibration, please set the energy threshold value lower than the displayed value. Set above value in D017 (Energy threshold of vortex flow signal) and D018 (Energy threshold of vibration), then set C49 back to 00.

VFM60 digital vortex flowmeter display can also indicate the self-diagnose code as below:

Error code	Problem	Repair
Err-003	Temperature sensor disconnected	Check Temperature sensor
Err-004	Pressure sensor disconnected	Check pressure sensor
Err-005	About to over total flow	This is a reminding message
Err-006	Display value over limit	The value is over the physical limit of the display
Err-011	Superheated steam temperature is over limited	Reduce the steam temperature
Err-012	Superheated steam pressure is over limited	Reduce the steam pressure
Err-013	Button is pressed and hold for too long time	Check the button circuit
Err-014	Reset code setting failed	Check EEPROM
Err-015	Reset digital setting failed	Check EEPROM
Err-016	Read total flow error	Check EEPROM
Err-017	Temperature calibration setting is wrong	Check the record of temperature calibration
Err-018	pressure calibration setting is wrong	Check the record of pressure calibration
Err-020	Flow rate limit setting is incorrect	Check the flow rate limit setting
Err-021	Temperature limit setting is incorrect	Check the temperature limit setting
Err-022	Pressure limit setting is incorrect	Check the pressure limit setting
Err-023	Communication connection error	Check the communication link
Err-024	Setting is incorrect when using aga_nx_19 to calculate the compressibility factor	Check if the setting for compressibility factor is correct
Err-025	Frequency output for total flow is over limit	Reset the total flow frequency output factor
Err-026	3V/1.5V power source failure	Check the circuit board
Err-027	Frequency output limit incorrect	Check the range of frequency
Err-029	The master is disconnected from the slave	Check the cable wiring between local and remote transmitter
Err-030	Pressure sensor valve closed	Check the switch status of the three-way valve

Err-036	The measured temperature is too high. The medium temperature exceeds the upper temperature limit.	Check whether the upper temperature limit is reasonable.
Err-037	The pipe and coefficient do not correspond.	Check whether the pipe size and coefficient settings are reasonable.
Err-049	Ambient temperature upper limit alarm.	Check whether the temperature of the meter head is too high or contact our company.
Err-050	Ambient temperature lower limit alarm.	Check whether the temperature of the meter head is too low or contact our company.

11 Remark

No part of this publication may be copied or distributed, transmitted, transcribed, stored in a retrieval system, or translated into any human or computer language, in any form or by any means, electronic, mechanical, manual, or otherwise, or disclosed to third parties without the express written permission of our company. The information contained in this manual is subject to change without notice.

Appendix

Specification

☐ Accuracy

Variables	For gas and steam	Liquid
Flow rate (m ³ /h)	±1% RD (Re ≥ 20000)	±0.75% RD (Re ≥ 20000)
	±2% RD (10000 < Re < 20000)	±2% RD (10000 < Re < 20000)
Mass flow (kg/h)	±1.5% RD (Re ≥ 20000)	±1.0% RD (Re ≥ 20000)
	±2.5% RD (10000 < Re < 20000)	±2.5% RD (10000 < Re < 20000)
Temperature (°C) (For multi-variable version)	±1 °C	±1 °C
Pressure (Mpa) (For multi-variable version)	±0.75% FS	±0.75% FS

☐ Repeatability

Flow rate	±0.3%
-----------	-------

Mass flow	$\pm 0.3\%$
Temperature	$\pm 0.05\text{ }^{\circ}\text{C}$
Pressure	$\pm 0.05\% \text{ FS}$

☐ Measurement range

Fluid type	Lower limit	Higher limit	Condition
Gas/steam	6m/s, DN15、DN20	60m/s	T=25℃, P=101.325Kpa Air calibrated
	4m/s, DN25、DN32		
	2m/s, DN40~DN300		
Liquid	0.3m/s	6m/s	T=25℃, P=101.325Kpa Water calibrated

☐ Temperature range


Normal temperature version	-40℃~150℃
Medium temperature version	-40℃~250℃
High temperature version	-40℃~350℃

☐ Pressure range

Available pressure rating includes 1.6Mpa, 2.5Mpa, 4.0Mpa, 6.3 Mpa. If the application requires a higher-pressure rating, please contact us to check the possibility.

Size and dimension

Size and dimension for wafer type






Size	K (Pipe O/D)	L (Pipe length)	W (Flange screw hole distance)	C (flange thickness)	m (screw hole diameter)	n (screw qty)	H (Meter height) 150dgrC	H (Meter height) 250dgrC	H (Meter height) 350dgrC	Flange O/D
15	75	65	100	18	14	4	294	335	475	130
20	75	65	100	18	14	4	294	335	475	130
25	75	65	100	18	14	4	299	340	480	130
32	80	65	120	20	14	4	292.8	333.8	473.8	145
40	84	65	120	20	14	4	295.8	336.8	476.8	145
50	94	65	132	22	18	4	301	342	482	160
65	105	65	144	24	18	4	308.5	349.5	489.5	180
80	120	65	160	24	18	6	316	357	497	192
100	140	90	190	24	18	8	327	368	508	230
125	165	65	210	26	18	8	340.5	381.5	521.5	242
150	190	65	240	28	22	8	353	534	534	280
200	240	85	296	28	22	12	378	559	559	335
250	290	100	354	28	22	12	404	585	585	405
300	340	120	412	30	22	12	429	609	609	460

Remark: The flange O/D, screw holes distance, flange thickness, screw hole diameter and screw qty are for the counter flanges, unit in mm.

Counter flanges, screw and bolts, gaskets are usually along with package except customer do not need them.

Size and dimension for flanged type

		
VFM60N Flanged type 150 dgrC version	VFM60N Flanged type 250 dgrC version	VFM60N Flanged type 350 dgrC version

Dimension of ANSI CL150 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C(flange thickness)	m (screw hole diameter)	n(screw qty)	H (Meter height) 150dgrC	H (Meter height) 250dgrC	H (Meter height) 350dgrC
15	90	181	60.3	11.6	16	4	294	335	475
20	100	191	69.9	13.2	16	4	294	335	475
25	110	197	79.4	14.7	16	4	299	340	480
32	115	201	88.9	16.3	16	4	294	335	475
40	125	209	98.4	17.9	16	4	296	337	477
50	150	213	120.7	19.5	18	4	301	342	482
65	180	225	139.7	22.7	18	4	309	350	490
80	190	235	152.4	24.3	18	4	316	357	497
100	230	259	190.5	24.3	18	8	327	368	508
125	255	308	215.9	24.3	22	8	341	382	522
150	280	323	241.3	25.9	22	8	353	534	534
200	345	349	298.5	29	22	8	378	559	559
250	405	369	362	30.6	26	12	404	585	585
300	485	415	431.8	32.2	26	12	429	610	610

Dimension of ANSI CL300 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C(flange thickness)	m (screw hole diameter)	n(screw qty)	H (Meter height) 150dgrC	H (Meter height) 250dgrC	H (Meter height) 350dgrC
15	95	191	66.7	14.7	16	4	294	335	475
20	115	201	82.6	16.3	18	4	294	335	475
25	125	209	88.9	17.9	18	4	299	340	480

VFM-60

Vortex Flowmeter

32	135	217	98.4	19.5	18	4	294	335	475
40	155	223	114.3	21.1	22	4	296	337	477
50	165	225	127	22.7	18	8	301	342	482
65	190	239	149.2	25.9	22	8	309	350	490
80	210	255	168.3	29	22	8	316	357	497
100	255	277	200	32.2	22	8	327	368	508
125	280	328	235	35.4	22	8	341	382	522
150	320	343	269.9	37	22	12	353	534	534
200	380	369	330.2	41.7	26	12	378	559	559
250	445	401	387.4	48.1	30	16	404	585	585
300	520	447	450.8	51.3	33	16	429	610	610

Dimension of DIN PN16 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C(flange thickness)	m (screw hole diameter)	n(screw qty)	H (Meter height) 150dgrC	H (Meter height) 250dgrC	H (Meter height) 350dgrC
15	95	161	65	16	14	4	294	335	475
20	105	165	75	18	14	4	294	335	475
25	115	165	85	18	14	4	299	340	480
32	140	169	100	18	18	4	294	335	475
40	150	175	110	18	18	4	296	337	477
50	165	175	125	18	18	4	301	342	482
65	185	175	145	18	18	8	309	350	490
80	200	195	160	20	18	8	316	357	497
100	220	209	180	20	18	8	327	368	508
125	250	240	210	22	18	8	341	382	522
150	285	255	240	22	22	8	353	534	534
200	340	269	295	24	22	12	378	559	559
250	405	305	355	26	26	12	404	585	585
300	460	341	410	28	26	12	429	610	610

Dimension of DIN PN25 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C(flange thickness)	m (screw hole diameter)	n(screw qty)	H (Meter height) 150dgrC	H (Meter height) 250dgrC	H (Meter height) 350dgrC
15	95	161	65	16	14	4	294	335	475
20	105	165	75	18	14	4	294	335	475
25	115	165	85	18	14	4	299	340	480
32	140	169	100	18	18	4	294	335	475

Rev1.8

User's Manual

VFM-60

Vortex Flowmeter

40	150	175	110	18	18	4	296	337	477
50	165	181	125	20	18	4	301	342	482
65	185	189	145	22	18	8	309	350	490
80	200	211	160	24	18	8	316	357	497
100	235	235	190	24	22	8	327	368	508
125	270	266	220	26	26	8	341	382	522
150	300	295	250	28	26	8	353	534	534
200	360	305	310	30	26	12	378	559	559
250	425	341	370	32	30	12	404	585	585
300	485	369	430	34	30	16	429	610	610

Dimension of DIN PN40 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C(flange thickness)	m (screw hole diameter)	n(screw qty)	H (Meter height) 150dgrC	H (Meter height) 250dgrC	H (Meter height) 350dgrC
15	95	161	65	16	14	4	294	335	475
20	105	165	75	18	14	4	294	335	475
25	115	165	85	18	14	4	299	340	480
32	140	169	100	18	18	4	294	335	475
40	150	175	110	18	18	4	296	337	477
50	165	181	125	20	18	4	301	342	482
65	185	189	145	22	18	8	309	350	490
80	200	211	160	24	18	8	316	357	497
100	235	235	190	24	22	8	327	368	508
125	270	266	220	26	26	8	341	382	522
150	300	295	250	28	26	8	353	534	534
200	375	321	320	34	30	12	378	559	559
250	450	375	385	38	33	12	404	585	585
300	515	415	450	42	33	16	429	610	610

Dimension of DIN PN63 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C(flange thickness)	m (screw hole diameter)	n(screw qty)	H (Meter height) 150dgrC	H (Meter height) 250dgrC	H (Meter height) 350dgrC
15	105	180	75	20	14	4	294	335	475
20	130	186	90	22	18	4	294	335	475
25	140	206	100	24	18	4	299	340	480
32	155	210	110	24	22	4	294	335	475
40	170	214	125	26	22	4	296	337	477
50	180	214	135	26	22	4	301	342	482
65	205	226	160	26	22	8	309	350	490

Rev1.8

User's Manual

VFM-60

Vortex Flowmeter

80	215	240	170	28	22	8	316	357	497
100	250	261	200	30	26	8	327	368	508
125	295	306	240	34	30	8	341	382	522
150	345	335	280	36	33	8	353	534	534
200	415	365	345	42	36	12	378	559	559
250	470	415	400	46	36	12	404	585	585
300	530	465	460	52	36	16	429	610	610

Dimension of JIS 10K flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C(flange thickness)	m (screw hole diameter)	n(screw qty)	H (Meter height) 150dgrC	H (Meter height) 250dgrC	H (Meter height) 350dgrC
15	95	147	70	12	15	4	294	335	475
20	100	149	75	14	15	4	294	335	475
25	125	157	90	14	19	4	299	340	480
32	135	161	100	16	19	4	294	335	475
40	140	161	105	18	19	4	296	337	477
50	155	165	120	16	19	4	301	342	482
65	175	173	140	18	19	4	309	350	490
80	185	185	150	18	19	8	316	357	497
100	210	195	175	18	19	8	327	368	508
125	250	224	210	20	23	8	341	382	522
150	280	251	240	22	23	8	353	534	534
200	330	261	290	22	23	12	378	559	559
250	400	295	355	24	25	12	404	585	585
300	445	321	400	24	25	16	429	610	610

Dimension of JIS 20K flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C(flange thickness)	m (screw hole diameter)	n(screw qty)	H (Meter height) 150dgrC	H (Meter height) 250dgrC	H (Meter height) 350dgrC
15	95	153	70	14	15	4	294	335	475
20	100	157	75	16	15	4	294	335	475
25	125	161	90	16	19	4	299	340	480
32	135	167	100	18	19	4	294	335	475
40	140	167	105	18	19	4	296	337	477
50	155	169	120	18	19	8	301	342	482
65	175	181	140	20	19	8	309	350	490
80	200	197	160	22	23	8	316	357	497
100	225	221	185	24	23	8	327	368	508

Rev1.8

User's Manual

VFM-60


Vortex Flowmeter

125	270	258	225	26	25	8	341	382	522
150	305	291	260	28	25	12	353	534	534
200	350	299	305	30	25	12	378	559	559
250	430	339	380	34	27	12	404	585	585
300	480	373	430	36	27	16	429	610	610

Remark:

- (1) Flanged version do not contains screws and bolts in the package unless customer need to purchase from us. We also have flanged type in other standard and pressure rating. Please check with us if you require flanged version other than what we provided
- (2) The flange outer diameter K, center hole distance W, flange thickness C, height H, screw hole diameter m, and number of bolts n in the table are the matching flange size parameters, unit mm.
- (3) The meter body length L is the face to face distance, including the height of raised face, don't include the thickness of gasket.

□Size and dimension for multi-variable wafer type




Size	K (Pipe O/D)	L (Pipe length)	W(Flange screw hole distance)	C(flange thickness)	M (screw hole diameter)	n (screw qty)	L1 (Condensation pipe length)	H (Meter height) 150dgrC	H1 (Condensation pipe height 150 dgrC)	H (Meter height) 250dgrC	H1 (Condensation pipe height 250 dgrC)	H (Meter height) 350dgrC	H1 (Condensation pipe height 350 dgrC)
15	75	65	100	18	14	4	86	294	183	335	234	475	374
20	75	65	100	18	14	4	83.5	294	183	335	234	475	374
25	75	65	100	18	14	4	86	299	188	340	239	480	379
32	80	65	120	20	14	4	87	292.8	181.8	333.8	232.8	473.8	372.8
40	84	65	120	20	14	4	89	295.8	184.8	336.8	235.8	476.8	375.8
50	94	65	132	22	18	4	89	301	190	342	241	482	381
65	105	65	144	24	18	4	91	308.5	197.5	349.5	248.5	489.5	388.5
80	120	65	160	24	18	6	111	316	247.5	357	298.5	497	438.5
100	140	90	190	24	18	8	90	327	221	368	272	508	412
125	165	65	210	26	18	8	86	340.5	239.5	381.5	290.5	521.5	430.5
150	190	65	240	28	22	8	86	353	267	534	458	534	458

VFM-60

Vortex Flowmeter

200	240	85	296	28	22	12	106	378	317	559	508	559	508
250	290	100	354	28	22	12	106	404	368	585	559	585	559
300	340	120	412	30	22	12	106	429	418	609	609	609	609

□Size and dimension for multi-variable flanged type



Dimension of DIN PN16 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C (flange thickness)	m (screw hole diameter)	n (screw qty)	L1 (Condensation pipe length)	H (Meter height) 150dgrC	H1 (Condensation pipe height) 150 dgrC)	H (Meter height) 250dgrC	H1 (Condensation pipe height) 250 dgrC)	H (Meter height) 350dgrC	H1 (Condensation pipe height) 350 dgrC)
15	95	161	65	16	14	4	76	294	183	335	234	475	374
20	105	165	75	18	14	4	68.5	294	183	335	234	475	374
25	115	165	85	18	14	4	66	299	195.5	340	246.5	480	386.5
32	140	169	100	18	18	4	57	294	193.5	335	244.5	475	384.5
40	150	175	110	18	18	4	56	296	195.5	337	246.5	477	386.5
50	165	175	125	18	18	4	53.5	301	200	342	251	482	391
65	185	175	145	18	18	8	51	309	207	350	258	490	398
80	200	195	160	20	18	8	51	316	219	357	270	497	410
100	220	209	180	20	18	8	50	327	234	368	285	508	425
125	250	240	210	22	18	8	43.5	341	248	382	299	522	439
150	285	255	240	22	22	8	38.5	353	278	534	469	534	469
200	340	269	295	24	22	12	56	378	328	559	519	559	519
250	405	305	355	26	26	12	48.5	404	380.7	585	571.7	585	571.7
300	460	341	410	28	26	12	46	429	438.4	610	629.4	610	629.4

Dimension of DIN PN25 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C (flange thickness)	m (screw hole diameter)	n (screw qty)	L1 (Condensation pipe length)	H (Meter height) 150dgrC	H1 (Condensation pipe height) 150 dgrC)	H (Meter height) 250dgrC	H1 (Condensation pipe height) 250 dgrC)	H (Meter height) 350dgrC	H1 (Condensation pipe height) 350 dgrC)
15	95	161	65	16	14	4	76	294	183	335	234	475	374
20	105	165	75	18	14	4	68.5	294	183	335	234	475	374
25	115	165	85	18	14	4	66	299	195.5	340	246.5	480	386.5
32	140	169	100	18	18	4	57	294	193.5	335	244.5	475	384.5
40	150	175	110	18	18	4	56	296	195.5	337	246.5	477	386.5
50	165	181	125	20	18	4	53.5	301	200	342	251	482	391
65	185	189	145	22	18	8	51	309	207	350	258	490	398
80	200	211	160	24	18	8	51	316	219	357	270	497	410
100	235	235	190	24	22	8	32.5	327	234	368	285	508	425
125	270	266	220	26	26	8	33.5	341	248	382	299	522	439
150	300	295	250	28	26	8	31	353	278	534	469	534	469
200	360	305	310	30	26	12	46	378	328	559	519	559	519
250	425	341	370	32	30	12	38.5	404	380.7	585	571.7	585	571.7
300	485	369	430	34	30	16	33.5	429	438.4	610	629.4	610	629.4

Dimension of DIN PN40 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C (flange thickness)	m (screw hole diameter)	n (screw qty)	L1 (Condensation pipe length)	H (Meter height) 150dgrC	H1 (Condensation pipe height) 150 dgrC)	H (Meter height) 250dgrC	H1 (Condensation pipe height) 250 dgrC)	H (Meter height) 350dgrC	H1 (Condensation pipe height) 350 dgrC)
15	95	161	65	16	14	4	76	294	183	335	234	475	374
20	105	165	75	18	14	4	68.5	294	183	335	234	475	374
25	115	165	85	18	14	4	66	299	195.5	340	246.5	480	386.5
32	140	169	100	18	18	4	57	294	193.5	335	244.5	475	384.5
40	150	175	110	18	18	4	56	296	195.5	337	246.5	477	386.5
50	165	181	125	20	18	4	53.5	301	200	342	251	482	391
65	185	189	145	22	18	8	51	309	207	350	258	490	398
80	200	211	160	24	18	8	51	316	219	357	270	497	410
100	235	235	190	24	22	8	32.5	327	234	368	285	508	425
125	270	266	220	26	26	8	33.5	341	248	382	299	522	439
150	300	295	250	28	26	8	31	353	278	534	469	534	469
200	375	321	320	34	30	12	39.5	378	328	559	519	559	519
250	450	375	385	38	33	12	36	404	380.7	585	571.7	585	571.7
300	515	415	450	42	33	16	18.5	429	438.4	610	629.4	610	629.4

Dimension of DIN PN63 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C (flange thickness)	m (screw hole diameter)	n (screw qty)	L1 (Condensation pipe length)	H (Meter height) 150dgrC	H1 (Condensation pipe height) 150 dgrC)	H (Meter height) 250dgrC	H1 (Condensation pipe height) 250 dgrC)	H (Meter height) 350dgrC	H1 (Condensation pipe height) 350 dgrC)
15	105	180	75	20	14	4	76	294	183	335	234	475	374
20	130	186	90	22	18	4	68.5	294	183	335	234	475	374
25	140	206	100	24	18	4	66	299	195.5	340	246.5	480	386.5
32	155	210	110	24	22	4	57	294	193.5	335	244.5	475	384.5
40	170	214	125	26	22	4	56	296	195.5	337	246.5	477	386.5
50	180	214	135	26	22	4	53.5	301	200	342	251	482	391
65	205	226	160	26	22	8	51	309	207	350	258	490	398
80	215	240	170	28	22	8	51	316	219	357	270	497	410
100	250	261	200	30	26	8	32.5	327	234	368	285	508	425
125	295	306	240	34	30	8	33.5	341	248	382	299	522	439
150	345	335	280	36	33	8	31	353	278	534	469	534	469
200	415	365	345	42	36	12	39.5	378	328	559	519	559	519
250	470	415	400	46	36	12	36	404	380.7	585	571.7	585	571.7
300	530	465	460	52	36	16	18.5	429	438.4	610	629.4	610	629.4

Dimension of ANSI CL150 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C (flange thickness)	m (screw hole diameter)	n (screw qty)	L1 (Condensation pipe length)	H (Meter height) 150dgrC	H1 (Condensation pipe height) 150 dgrC)	H (Meter height) 250dgrC	H1 (Condensation pipe height) 250 dgrC)	H (Meter height) 350dgrC	H1 (Condensation pipe height) 350 dgrC)
15	90	181	60.3	11.6	16	4	76	294	183	335	234	475	374
20	100	191	69.9	13.2	16	4	68.5	294	183	335	234	475	374
25	110	197	79.4	14.7	16	4	66	299	195.5	340	246.5	480	386.5
32	115	201	88.9	16.3	16	4	57	294	193.5	335	244.5	475	384.5
40	125	209	98.4	17.9	16	4	56	296	195.5	337	246.5	477	386.5
50	150	213	120.7	19.5	18	4	53.5	301	200	342	251	482	391
65	180	225	139.7	22.7	18	4	51	309	207	350	258	490	398
80	190	235	152.4	24.3	18	4	51	316	219	357	270	497	410
100	230	259	190.5	24.3	18	8	32.5	327	234	368	285	508	425
125	255	308	215.9	24.3	22	8	33.5	341	248	382	299	522	439
150	280	323	241.3	25.9	22	8	31	353	278	534	469	534	469
200	345	349	298.5	29	22	8	39.5	378	328	559	519	559	519
250	405	369	362	30.6	26	12	36	404	380.7	585	571.7	585	571.7
300	485	415	431.8	32.2	26	12	18.5	429	438.4	610	629.4	610	629.4

Dimension of ANSI CL300 flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C (flange thickness)	m (screw hole diameter)	n (screw qty)	L1 (Condensation pipe length)	H (Meter height) 150dgrC	H1 (Condensation pipe height 150 dgrC)	H (Meter height) 250dgrC	H1 (Condensation pipe height 250 dgrC)	H (Meter height) 350dgrC	H1 (Condensation pipe height 350 dgrC)
15	95	191	66.7	14.7	16	4	76	294	183	335	234	475	374
20	115	201	82.6	16.3	18	4	68.5	294	183	335	234	475	374
25	125	209	88.9	17.9	18	4	66	299	195.5	340	246.5	480	386.5
32	135	217	98.4	19.5	18	4	57	294	193.5	335	244.5	475	384.5
40	155	223	114.3	21.1	22	4	56	296	195.5	337	246.5	477	386.5
50	165	225	127	22.7	18	8	53.5	301	200	342	251	482	391
65	190	239	149.2	25.9	22	8	51	309	207	350	258	490	398
80	210	255	168.3	29	22	8	51	316	219	357	270	497	410
100	255	277	200	32.2	22	8	32.5	327	234	368	285	508	425
125	280	328	235	35.4	22	8	33.5	341	248	382	299	522	439
150	320	343	269.9	37	22	12	31	353	278	534	469	534	469
200	380	369	330.2	41.7	26	12	39.5	378	328	559	519	559	519
250	445	401	387.4	48.1	30	16	36	404	380.7	585	571.7	585	571.7
300	520	447	450.8	51.3	33	16	18.5	429	438.4	610	629.4	610	629.4

Dimension of JIS 10K flanged version

Size	K(Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C (flange thickness)	m (screw hole diameter)	n (screw qty)	L1 (Condensation pipe length)	H (Meter height) 150dgrC	H1 (Condensation pipe height 150 dgrC)	H (Meter height) 250dgrC	H1 (Condensation pipe height 250 dgrC)	H (Meter height) 350dgrC	H1 (Condensation pipe height 350 dgrC)
15	95	147	70	12	15	4	76	294	183	335	234	475	374
20	100	149	75	14	15	4	68.5	294	183	335	234	475	374
25	125	157	90	14	19	4	66	299	195.5	340	246.5	480	386.5
32	135	161	100	16	19	4	57	294	193.5	335	244.5	475	384.5
40	140	161	105	18	19	4	56	296	195.5	337	246.5	477	386.5
50	155	165	120	16	19	4	53.5	301	200	342	251	482	391
65	175	173	140	18	19	4	51	309	207	350	258	490	398
80	185	185	150	18	19	8	51	316	219	357	270	497	410
100	210	195	175	18	19	8	32.5	327	234	368	285	508	425
125	250	224	210	20	23	8	33.5	341	248	382	299	522	439
150	280	251	240	22	23	8	31	353	278	534	469	534	469
200	330	261	290	22	23	12	39.5	378	328	559	519	559	519
250	400	295	355	24	25	12	36	404	380.7	585	571.7	585	571.7
300	445	321	400	24	25	16	18.5	429	438.4	610	629.4	610	629.4


Dimension of JIS 20K flanged version

Size	K (Flange O/D)	L(Pipe length)	W(Flange screw hole distance)	C (flange thickness)	m (screw hole diameter)	n (screw qty)	L1 (Condensation pipe length)	H (Meter height) 150dgrC	H1 (Condensation pipe height 150 dgrC)	H (Meter height) 250dgrC	H1 (Condensation pipe height 250 dgrC)	H (Meter height) 350dgrC	H1 (Condensation pipe height 350 dgrC)
15	95	153	70	14	15	4	76	294	183	335	234	475	374
20	100	157	75	16	15	4	68.5	294	183	335	234	475	374
25	125	161	90	16	19	4	66	299	195.5	340	246.5	480	386.5
32	135	167	100	18	19	4	57	294	193.5	335	244.5	475	384.5
40	140	167	105	18	19	4	56	296	195.5	337	246.5	477	386.5
50	155	169	120	18	19	8	53.5	301	200	342	251	482	391
65	175	181	140	20	19	8	51	309	207	350	258	490	398
80	200	197	160	22	23	8	51	316	219	357	270	497	410
100	225	221	185	24	23	8	32.5	327	234	368	285	508	425
125	270	258	225	26	25	8	33.5	341	248	382	299	522	439
150	305	291	260	28	25	12	31	353	278	534	469	534	469
200	350	299	305	30	25	12	39.5	378	328	559	519	559	519
250	430	339	380	34	27	12	36	404	380.7	585	571.7	585	571.7
300	480	373	430	36	27	16	18.5	429	438.4	610	629.4	610	629.4

Remark:

- (1) Flanged version do not contains screws and bolts in the package unless customer need to purchase from us. We also have flanged type in other standard and pressure rating. Please check with us if you require flanged version other than what we provided
- (2) The flange outer diameter K, center hole distance W, flange thickness C, height H, screw hole diameter m, and number of bolts n in the table are the matching flange size parameters, unit mm.
- (3) The meter body length L is the face to face distance, including the height of raised face, don't include the thickness of gasket.

□ Size and dimension for remote converter



BELL
Flow Systems